



Information

The Stair Stretcher Pro is a new design which allows the user to remove the stair-climber wheels using the quick release button system.

This lightweight funeral stretcher is robust enough for most removals and benefits from having a contoured foot end to aid manoeuvrability in tight spaces. The clever tri-wheel assembly has been neatly brought into the frame width allowing controlled descent of almost any stairs at any angle.

Specifications

Length	73.5" / 187cm	Stair Attachment Width	23.5" / 60cm
Length (folded)	36" / 91cm	Weight	12.5Kg
Width	20.5" / 51.5cm	Max Load	165kg / 26st
Height	8.5" / 22cm		

2 x Straps Included



WoodWynd Consulting

www.audenaustralia.com | info@audenaustralia.com | 0420 606 843