



Information

The Super XLS is a high strength easy to operate removal trolley. With an industry leading load capacity of 475 Kgs.

The single height trolley benefits from our independent leg operation.

It also has our folding sidearms which when used significantly increases the surface area to securely contain body mass. This trolley delivers both safety and practicality.

Furthermore, the Super XLS offers the convenience of our optional “easy-out wheel” system, eliminating the need for lifting when exiting your vehicle.

Specifications

Length	193cm
Loading Wheel Width	72cm
Max Width (arm sides out)	97cm
Height (mattress)	79cm
Min Height (bed)	28cm
Loading Wheel Height	61cm
Weight	33kg
Max Load	475 kgs

Side Arms

The side arms lock into four positions:

Upright – Providing containment

45 degree – Improved containment

Flat – Gives extra surface area

Included

Mattress, 3 Straps, 1 Extra Large Body Cover



WoodWynd Consulting

www.audenaustralia.com | info@audenaustralia.com | 0420 606 843